
FIG. 1








FIG. 3


OPERATION MODE	START OF INTERNAL COMBUSTION ENGINE	TORQUE ASSIST FOR INTERNAL COMBUSTION ENGINE	POWER GENERATION
CONTROL	(STEP-UP CHOPPER)+ STRONG MAGNETIC FIELD	(STEP-UP CHOPPER)+ STRONG MAGNETIC FIELD WEAK MAGNETIC FIELD	STEP-DOWN CHOPPER+ WEAK MAGNETIC FIELD


FIG. 5








ENGINE SPEED(Ng)
IDLING SPEED(Ni)
Vg:POWER GENERATION
VOLTAGE
Vb:BATTERY CHARGING
VOLTAGE














FIG. 12(a)




FIG. 12(b)

